NAVIONICS®

Platinum+™ LOWRANCE®

Platinum+ QuickStart Card
For Lowrance HDS models:

For a full description of how to display Navionics Platinum+ Chart features in a variety of ways, please refer to your Lowrance User's Manual.

Getting Started

To access Navionics on your Lowrance HDS unit:

- Insert your Navionics card in the card slot.
- Press PAGES to select the Chart menu and press ENTER.
- Press MENU twice.
- Select Chart and press ENTER.
- Select Chart Data and press ENTER.
- Select Navionics and press ENTER.



Shortcut: *Softkeys available on some models for quick access to menus.*

Panoramic Photos

To display a panoramic photo:

- Place cursor cross-hair over camera symbol.
- Press ENTER to view photo.

NOTE: To view camera symbols, the map screen must be zoomed in to at least the .5nm. The position of the camera symbol indicates the direction in which the photo was taken.

3D View



To display 3D view:

- Press MENU.
- Select Chart Options and press ENTER.
- Select View and press ENTER.
- Select 3D and press ENTER.



Lowrance HDS chart menu



Navionics chart data selection

Panoramic photo symbol *Panoramic photo*



Select 3D/2D view

NAVIONICS®

Platinum+™

LOWRANCE®



Shortcut: *Softkeys available on some models for quick access to menus.*

Shading

To display map shading:

- Press MENU.
- Select Chart Options and press ENTER.
- Select Shading and press ENTER to enable/disable shading.

Note: 3D cartography can be viewed in full screen, split screen, and in a variety of views. Refer to your User's Manual for more information.

Photo Overlay

To display Aerial or Satellite Photos:

- Press MENU.
- Select Chart Options and press ENTER.
- Select Photo Overlay and press ENTER.
- Select Off, Land only, Land and shallow water, or Full and press ENTER.

To change photo transparency:

- Select Photo Transparency.
- Use right and left arrows to increase and decrease Photo transparency level.

Fish'N Chip

To display Fish'N Chip:

- Press MENU.
- Select Chart Options, then press ENTER.
- Select Fish'N Chip, then press ENTER to enable/disable Fish'N Chip data.

Navionics exclusive feature! Adjustable depth shading.

- Press MENU.
- Select Chart Options and press ENTER.
- Select Settings and press ENTER.
- Select Safety Depth or Contours Depth and press ENTER.
- Select preferred depth setting and press ENTER.



Disable/enable shading

3D chart view with land only photo overlay

Photo overlay selection

Photo overlay on land only at level 5 transparency



Fishing data layer